

## Use drink programs wherever possible

**P L M**

buttons are single speeds for miscellaneous blending

## WestBerryQ 9700

commercial smoothie blender

### Control Panel

## Drinks programs

**1**

Press drink you wish to blend

**2**

Then press 'start blend'

**3**

Blender will stop automatically when drink is made





**WestBerryQ 9700**

## Take precautions when operating the blender

1. Never operate blender without blender jar lid and sound enclosure lid in place and in closed position
2. Never touch blade at any time as it is sharp
3. Do not attempt to remove or place jar unless blender is at a full stop
4. Do not overfill jar beyond marked measure
5. Do not attempt to override safety features
6. Never run blender jar 'dry' without liquid
7. If testing, put 1" (25ml) water into jar
8. When blending food or fruit there must be a percentage of liquid in the jar otherwise the blender cannot blend. Failure to do so will cause motor to overheat
9. Do not wash blender jar or rubber lid in dishwasher. Wash in warm soapy water with soft cloth or sponge, using a soft nylon brush to wash around blade. Rinse jar to remove residues of soap. Upright jar & leave on sink draining board to dry
10. Do not use abrasives of any kind as this will leave unsightly marks on plastic finish. Use damp soft cloth, sponge and dry paper towel only for cleaning and drying
11. Only use fruit & food items for blending. Do not allow metal, stone, glass, bones or hard kernels from fruit e.g. peach stones entering the jar
12. Do not immerse motor base in water. Use damp soft cloth to wipe exterior. Dry with paper towel
13. Avoid touching metal drive on underside of jar and drive socket on top of blender motor base, as they may be very hot